

Radiator Guard Installation Instructions

Manufacturer : Gas Gas
Model : EC FSE/FSR
Year : 2003-2009 2005-2009
Note: 03-04 FSE Models require a different brace.

1. Remove the seat, radiator shrouds plastic radiator guards and radiator shroud nuts. Remove the 2 mounting bolts from each radiator.



Figure 1.

2. Fit the rear support to the frame as shown in figure 2.



Figure 2.

3. Fit the radiator guards using the M6 x 25mm bolts and washers supplied. Tightened with a 10 mm spanner.



Figure 3.

4. Fit the M6 x 16 mm bolts to the rear brace as shown in figure 4.



Figure 4.

5. Refit the radiator shrouds and seat.