

## Radiator Guard Installation Instructions

**Manufacturer :** Gas Gas  
**Model :** EC  
**Year :** 2005-2010  
**Part No:** FA-001-GG-04

**FSE/FSR**  
**2005-2011**

1. Remove the seat, radiator shrouds plastic radiator guards and radiator shroud nuts. Remove the 2 mounting bolts from each radiator.



Figure 1.

2. Fasten rear brace and radiator with supplied M6 x 25 mm bolts to frame (figure 2).



Figure 2.

3. Install radiator guards and fasten screws at front side ( ensure the lower rubber grommet on the outer face of the radiator locates on the M6 pressnut on the inside of the new guard, this function holds the radiator from moving to freely ) fasten brace to guard at rear with with supplied M6 x 12 button head screws ( figure 3 )



Figure 3

4. Refit the radiator shrouds and seat.