

Radiator Guard Installation Instructions

Manufacturer : Gas Gas
Model : EC 250/300
Year : 2012
Part No: FA-001-GG-05

1. Remove the seat, radiator shrouds & plastic radiator guards. Remove the 2 mounting bolts from each radiator.
2. Remove the 4 thick washers between each radiator and frame. These washers will be replaced by the rear radiator brace.



3. The bolts in the radiator guard pass through the radiator mounting holes then through the rear brace and screw into the frame.
4. Fasten brace to guard at rear with with supplied M6 x 12 bolts.
5. Tighten all fasteners. An 8mm T-bar is required to tighten the main radiator guard bolts.
6. Refit the radiator shrouds and seat.

