

GAS GAS Radiator Guard Installation Instructions

EC300/XC300 2018+

FA-001-GG-06



TOOLS REQUIRED:
6MM, 8MM SOCKET OR T-BAR

1: Pull left hand side cover off to access the seat bolt, remove bolt and take seat off.



2: Take tank shrouds off by undoing the 6mm and 8mm bolts.



3: Take off the black plastic covers off the Radiators.

4: Remove all bolts that hold the Radiators to frame.

5: Fit the 2 braces to the Radiator Guards and tighten all bolts before attaching to the bike.

The large brace goes to the right hand side and the small to the left hand side



6: Now place the Radiator Guards onto bike and tighten all bolts.

7: Replace both tank covers with OEM bolts and tighten.

8: Fit seat, tighten bolt and place side cover back on bike.
Bike is now ready to ride.