

## Radiator Guard Installation Instructions

To suit: CRF450X 2005-2011  
FA-001-HA-02

1. Remove the radiator shrouds and plastic radiator guards. Remove the 2 mounting bolts from each radiator using an 8mm spanner. Also remove the clip nut from the lower radiator tab. Figure 1
2. On the RHS of the bike remove the mounting bolt for the horn (X models). On the 450X remove the bolts securing the electrical connectors near the shroud mounting hole on the frame.
3. Fit the radiator guards using a 10mm T-Bar or socket with extension. Figure 2.
4. Attach the braces to the radiator guards. On the 450X model re-fit the bolts that secure the electrical connectors. Figure 3
5. On the X models remount the horn on the RHS brace.
6. Refit the radiator shrouds



Figure 1.



Figure 2.



Figure 3.