

## Radiator Guard Installation Instructions

Model	Years	Part No.
CRF150R	2008-2011	FA-001-HA-07

1. Remove the radiator shrouds and plastic radiator guards. Remove the 2 mounting bolts from each radiator using an 8mm spanner. Also remove the clip nut from the lower radiator tab. Figure 1



Figure 1.

2. Fit the radiator guards using a 10mm T-Bar or socket with extension. Figure 2.



Figure 2.

3. Attach the brace across the bottom of the two radiator guards. Figure 3

4. Refit the radiator shrouds.

[www.forceaccessories.com.au](http://www.forceaccessories.com.au)  
Ph (03)9792 9599



Figure 3.