

Radiator Guard Installation Instructions

Model: Honda CRF250R
Part No: FA-001-HA-17

Year: 2018

Tools required:
8mm T-bar, 10mm T-bar

1. Remove the front fairings by removing the bolts. Also remove the plastic radiator guards/louvers.
2. Remove the 2 mounting bolts on the front of each radiator (Figure 2).
3. Bolt the radiator guards in place on each side. See figure 2.
4. Install the radiator brace by bolting the upper bolt through both the brace, radiator tab and radiator guard and the lower bolt through the fairing, brace, radiator tab and radiator guard.
5. Reinstall remaining fairing bolts.



Figure 2: Fitting radiator guards