

Model : KTM 2 & 4 Stroke
Year : 2008-2010
Part No: FA-001-KT-06

1. Remove the seat, fuel tank and plastic radiator guards. Remove the 2 radiator mounting screws from each radiator.
2. Fit the rear support to the frame. On the 4 stroke the bracket sits on top of the frame as shown in figure 1. On the 2 stroke the bracket is fitted to the bottom of the frame. It may be necessary to rotate the regulator to clear the bracket as shown in figure 2. Leave the clamping bolt loose until the radiator guards are fitted.



Figure 1.

3. Fit the 2 rear braces as shown in figure 3. Tighten the 2 bolts that attach the braces to the radiator. Leave the bolt loose that attaches the brace to the rear bracket until the radiator guards are fitted.
4. Fit the radiator guards. As the mounting points for the radiator guards are recessed, a 10mm spacer is required on each bolt as shown in figure 4. The two retaining bolts can be tightened using a 10mm T-bar, socket or spanner. Tighten all screws.



Figure 2.

Note: The radiator guard bolts to the front face of the tab on the radiator. Do not hook the guard over the tab on the radiator.

5. An M6 thread is provided on the front of the right radiator guard for mounting the horn if required.
6. Refit the fuel tank and seat. When refitting the tank, the side shroud mounting points slide in between the radiator and radiator guard. Use the 2 M6 washers provided. If it is a tight fit, the guards can be loosened with a 10mm spanner while fitting the tank.



Figure 3.



Figure 4.