

Radiator Guard Installation Instructions

Model : KTM SX-F
Year : 2011
Part No: FA-001-KT-07

1. Remove the seat, fuel tank and plastic radiator guards. Remove the 2 radiator mounting screws from each radiator.
2. Slide each radiator off its mounting lugs and fit the frame guard as per Fig 1. Bolt the radiators back onto the frame using the M6x16 hex head bolts provided
3. Fit the 2 rear braces as shown in figure 2. Do not tighten bolts.
4. Fit the 2 side braces as shown in figure 3
5. Tighten all bolts.
6. Fit either the metal screens provided or the standard plastic louvres (figure 4)



Figure 1.



Figure 2.



Figure 3.



Figure 4.