

**Model:** Suzuki RMZ250  
**Part No:** FA-001-SZ-07

**Year:** 2014

Tools required:  
8mm T-bar

1. Remove the fairings by removing the bolts circled in figure 1. Also remove the plastic radiator guards/louvers.



Figure 1: Mounting bolts for the fairings

2. Remove the 2 mounting bolts on the front of each radiator (Figure 2a).
3. Bolt the radiator guards in place on each side. See figure 2a.
4. Remove the bolt circled in figure 2b.



Figure 2: Fitting radiator guards and clamps (From left to right; a, b & c)

5. Bolt the guard brace to the guard and the frame. (Figure 3) For the bolt circled in yellow, just use the stock bolt. Use an OEM M6x16 bolt for the bolt circled in blue and the supplied M6x16 bolts with spacers in between the guards and braces for the bolts circled in green. Be sure that the lower hole (circled in red) without a bolt in it lines up with the thread on the guard, and remember to also use a spacer here when fitting the fairing.



Figure 3: Fitting radiator braces

6. Refit the fairings using the stock bolts for the upper 3 holes and the supplied M6x20 bolt for the lower hole.