

Model : WR250R  
Part No : FA-001-YA-09

Year : 2010 - 2016

1. Take off the seat by removing the two bolts in the rear wheel arch. Remove the radiator shroud. Also remove the plastic radiator guard/louver (it clips out)



Figure 1: Mounting bolts for the seat and radiator shrouds

2. Remove the plastic rear radiator/fan shroud by removing the 2 bolts circled in figure 2. This shroud will not be reinstalled. Also remove the bolt for the radiator hose bracket circled. The thermo fan remains bolted in place



3. Remove the radiator-to-frame mounting bolt and nut
4. Loosely bolt on the brace to the radiator hose bracket bolt hole (thereby reaffixing the radiator hose bracket) using the bolt and spacer provided
5. Loosely bolt on the radiator guard using the stock nut and the provided bolt.
6. Fasten the brace to the guard using the two m6x10mm bolts provided
7. Tighten the radiator-to-frame mounting bolt and nut and the brace-to-frame bolt



Figure 3: Fitted guard and brace

8. Refit the radiator shroud and the seat