

# Bashplate Installation Instructions

Model: TE 310-450-510  
Part No: FA-005-HQ-03

Year: 08-10

Tools required:  
8mm Socket, 13mm Spanner, (4, 5,6mm) Allen key



Figure 1: REMOVE ORIGINAL SKID PLATE

1. Remove the Original Skid Plate provided with the Bike by removing the bolts as shown above.



Figure 2: Remove the Clips from the Frame

2. Place the Bracket on the Frame at the specified location as shown in Figure 3 and fasten with supplied bolts



Figure 3: Place the Front Bracket (HQ-03) to the bike and mount with the supplied bolts



Figure 4: Place the 8mm alloy block (hq-03-f) on the top of the frame and (Hq-03-G) to the bottom of the frame and fasten with provided flathead bolts.



Figure 5: Slide bash plate over the aluminium blocks (from figure 4) that are mounted to the frame



Figure 6: Tighten the front bolt with 6mm Allen Key

3. Mount the front of the bash plate by fastening the front bolt onto the frame as shown above



Figure 7: Tighten the rear bolts as shown with 13mm spanner

4. Hold the nut on the main Bashplate bracket with a 13mm spanner as shown and tight the bolts from below.