

Model: Husqvarna TE310
Part No: FA-005-HQ-06

Year: 2011-2013

Tools required:
8mm Socket, 6mm Allen key, 5mm Allen key, 4mm Allen key, 13mm Spanner

1. Bolt the rear catch bracket to the Bashplate as shown in figure 1.



Figure 1- Mounting of rear catch bracket

2. Remove the Plastic Bashplate from the bike.
3. Fit the blocks of aluminium and stainless steel to the underside of the bike as shown in figure 2.



Figure 2 - Mounting of underside blocks

4. Mount the front bracket in between the frame rails towards the front of the bike (shown in figure 3). It may take a bit of menouvring to get into place. Get it into place by putting it in from the right side of the bike in between the engine and the frame rails. Once in place, bolt it to the frame using the M6 bolt supplied.



Figure 3 - Mounting of front bracket

5. Mount the Bashplate by first inserting the Bashplate and rear bracket over the blocks on the underside of the bike. Then bolt the front of the Bashplate to the front bracket using the supplied M8 bolt.



Figure 4 - Mounted Bashplate