

Model: Husqvarna XC-WR250-300 2S
Part No: FA-005-HQ-08

Year: 2009-2014

Tools required:
8mm Socket, 13mm spanner, 6mm Allen key, Threadlocker

1. Slide the front bracket up between the frame rails and put the bolt with its aluminium sleeve through the holes in the bracket as shown in figure 1. Then screw the nut on and tighten. Note, the bolt that goes through the bracket does not bolt to the bike in any way, it just sits over the frame rails.



Figure 1: Mounting the front bracket

2. Fit the Bashplate by first hooking the rear of it over the chassis tube between the foot pegs. Then bolt up the front of the Bashplate to the front bracket (using threadlocker).